

ALLIGATOR - DIGITAL OHMMETER SUBMITTAL SHEET WSC-0918

PRODUCT CODE

ACC-DGMTR

PRODUCT DESCRIPTION



The Warmup Alligator is an easy-to-use ohmmeter that comes with convenient connection clips. The Warmup Alligator can be used to constantly monitor a heating system during installation to prevent the installation of a damaged system. Final product readings gathered with an ohmmeter are required for warranty registration.

DIMENSIONS

Ohmmeter	35′ x 5″
Clip length	115 mm x 115 mm

APPLICATIONS

Use the Alligator with all Warmup products as required in the respective instruction manuals. For Insulation Resistance readings, refer to the ACC-MEGG digital Ohmmeter.

INSTRUCTIONS

To ensure that your floor heating system will function properly, always test the resistance of your wires with the Alligator before, during and after installation.

-Connect the red clip into the outlet labelled "V Ω mA" and the black connector into the "COM" outlet. Turn the dial so that the indicator points to the 6 o'clock position, directly above the "200 Ω " indicator

WARMUP INC. USA: us@warmup.com Tel.: 1-888-927-6333 www.warmup.com

CANADA: ca@warmup.com Tel.: 1-888-592-7687 www.warmup.ca





ALLIGATOR - DIGITAL OHMMETER SUBMITTAL SHEET WSC-0918

-Clip the alligator head of the black connector to the black wire of your heating system. The connect the alligator head of the red connector to the yellow wire. This is your "core to core" reading. Compare the ohm number that appears on the display to what the tag, box or installation manual state the reading should be for the model you purchased. Note: +/- 5% of the norm is acceptable.

-Next clip the alligator head of the black connector to the black wire of the floor heating system and the alligator head of the red connector to the yellow/green wire (neutral). You want to see the number "1" or the "infinity symbol – ∞ .". Now you will leave the red wire connected to the yellow/green wire but this time clip the black connector to the yellow wire of the floor heating system. Again, you want to see the number "1" or the infinity symbol.

TECHNICAL SUPPORT

Warmup is available 24/7/365 at (888) 927-6333. For quotes, layouts and specific technical information, contact us at:

Warmup USA 52 Federal Rd #1F, Danbury, CT 06810 (888) 927-6333 us@warmup.com

Warmup CANADA (888)592-7687 ca@warmup.com

WARMUP INC. USA: us@warmup.com Tel.: 1-888-927-6333 www.warmup.com

CANADA: ca@warmup.com Tel.: 1-888-592-7687 www.warmup.ca



The world's **best-selling** electric floor heating brand $^{\text{\tiny TM}}$